


DO-IT YOURSELF CANOPY TENT SETUP



STEP 1

Completely unfold your canopy on the ground. Drive stakes in ground 3 feet from the edge of the canopy. 1 stake from each side pole and 2 stakes at each corner pole, placed at the angle shown.

STEP 2



Next, fasten the ropes to the stakes. Leave the looped end of the rope free with about 7 feet of slack.

STEP 3

Set up the 2 piece side poles and place the tips of each pole through the brass grommets that are stitched into the canopy fabric. Be sure to place the metal ring over the tip of the pole that has been placed through the brass grommet.

SEE DIAGRAM TO RIGHT

FAILURE TO DO THIS MAY DAMAGE THE TENT




STEP 4

Angle the side poles at about 45 degrees. Now setup the larger diameter 4 piece center poles. Be certain to snap buttons connecting the pole sections are secure. **SEE DIAGRAM TO LEFT**

STEP 5

Push all the side poles vertical, attach and adjust all the guy ropes tight.



PLEASE READ THE FOLLOWING:

DO NOT use BBQ grills under your tent.

DO NOT make any fires under or near your tent.

Make sure all poles go through brass grommets and metal rings on tent to prevent fabric from tearing.

DO NOT stay under your tent during a storm.

READ ADDITIONAL WARNINGS ON INSIDE OF TENT VALANCE.

For product safety info visit www.UL.com/consumer/products.html & ask your rental clerk